CREATIVE.LIGHTING

SunsetAura™ Wall Light

Product manual



Safety information

Mount the light indoors using fixings suitable for your wall. Keep the charging port dry and the pull cords out of reach of young children.

What’s in the box

SunsetAura™ Wall Light, USB charging cable and mounting screws.

Product overview

The SunsetAura™ Wall Light is a cordless, rechargeable light for wall mounting. It combines sunrise and sunset effects with adjustable brightness and three white light tones.



Front panel and pull cords

Specifications

Materials	Iron and acrylic
Light tones	Warm, natural and cool white
Power	USB rechargeable
Battery runtime	Up to 14 hours
Installation	Wall mounted
Dimensions	30 × 30 × 5.8 cm 11.8 × 11.8 × 2.3 in

Setup

1. **Charge the light**
   Connect the included USB cable to the light’s charging port and a compatible USB power source. Disconnect the cable before mounting.

2. **Choose a mounting spot**
   Pick an indoor wall location with room for both cords to hang freely.

3. **Secure the light**
   Use the supplied screws if they suit your wall type. Check that the light is firmly mounted before using the pull cords.

How to use

Sunrise and sunset effects

Gently pull the cords to switch between sunrise and sunset effects.

Brightness and light tone

Use the touch controls to adjust brightness and select warm white, natural white or cool white.

Care and maintenance

Disconnect the USB cable before cleaning. Wipe the iron housing and acrylic panel with a soft, dry cloth. Avoid abrasive cloths and cleaners.

Troubleshooting

If the light does not respond, connect the included cable and check that the USB power source is on. If the issue continues after charging, please contact customer service.